

Premier 4-Car Bi-Level Passenger Set

OPERATOR'S MANUAL



Compatibility

This set of four Premier Bi-Level Cars, complete with control car, easily increases seating capacity on your hard working passenger lines. And the control unit, with its additional lights and cab, gives the illusion that it's taking charge when you back up a consist. The cars operate on O-42 or larger curved track.

PLEASE READ BEFORE USE AND SAVE

Table of Contents

Operating Control Car Lights	3
Changing Coach Car Lights	4
Changing Control Car Lights	5
Service & Warranty	11

CAUTION: ELECTRICALLY OPERATED PRODUCT:

Not recommended for children under 10 years of age. M.T.H. recommends adult supervision with children ages 10 - 16.

As with all electric products, precautions should be observed during handling and use to reduce the risk of electric shock.

WARNING: When using electrical products, basic safety precautions should be observed, including the following:

- WAKING: When using electrical products, basic safety precautions should be observed, including the following: Readthis manual thoroughly be fore using this device.

 M.T.H. recommends that all users and persons supervising use examine the hobby transformer and other between the periodically for conditions that may result in the risk of fire, electric shock, or injury to persos, such as damage to the primary cord, plug blades, housing, output jacks or other parts. In the event such conditions exist, the train set should not be used until cord, prug maues, nousing, output jaxes or visit parts.

 properly repaired.


 Do not operate your layout unattended. Obstructed accessories or stalled trains may overheat, resiting in damage to your layout.

 This train set is intended for indoor use. Do not use if water is present. Serious injury or fata lity may result.

 Do not operate the hobby transformer with damaged cord, plug, switches, buttons or case.

Turning Control Car Lights On/Off


Control car lights are operated by two switches under the car.



Switch 1: controls headlights and marker lights.

Position 1= headlight on and marker lights off Position 2= headlight and marker lights all off Position 3= headlight off and marker lights on **Switch 2:** control emergency stop light


Position 1= emergency stop light on Positions 2 & 3 = emergency stop light off



Changing the Roof Lights - Coach Car


To access roof lights:

From both trucks: remove the ground strap (by removing the screw)




Electrical Connector

and pull the wire from the electrical connector.




Remove 8 recessed screws.



Unplug Harness From Circuit Board


Carefully lift shell and disconnect wire connector.

To replace the roof bulbs, grasp the base (not the bulb itself) firmly with a pair of needlenose pliers and pull gently. If you have difficulty reaching the bulbs, you may unscrew the roof light mount and remove it from the car for easier access.




Changing The Roof Lights - Control Car


From both trucks: remove the ground strap (by removing the screw) and pull the wire from the electrical connector.




Remove 8 recessed screws.




Carefully lift shell and disconnect wire connector.



Unplug Harness From Circuit Board



Headlights and Emergency Stop Light:
1. Unscrew and remove the roof light mount that holds the lighting wires in place and the clip that secures the wires to the roof of the



- 2. Remove two screws from black headlight housing and pull housing back until bulbs pull away from car body.
- 3. Pull the bulbs from the housing and remove the wires and two-pin connectors. Replace entire LED unit.
- 4. When reassembling, secure black headlight housing into place and tuck wires securely into their tracks under the roof light mount and through clip.


Marker Lights:

- 1. Unscrew and remove the clip that secures the wires to the roof of the car.
- 2. Remove hot melt glue holding bulbs into place.
- 3. Pull light bulbs inside shell to remove them, and remove bulbs, wires, and two-pin connector. Replace entire unit and use hot glue to secure bulbs back into place.
- 4. When reassembling, be sure to tuck the wires into the guides and under the clip.

If you had to pull any of the lighting wires from their track in order to change the bulbs, tuck them carefully back into place to prevent harmful contact with other internal parts and from hanging down into sight once the car is reassembled and operating.

To access the interior lights:

Follow steps for accessing roof lights, then:




Remove six remaining screws in undercarriage.


Lift the bi-level interior from the base.




Remove the PCB board from the upper platform.



Remove the eight recessed screws from the bottom of the lower level.




Pull the two levels apart and replace the interior lights.



Reassemble, being careful not to pinch any wires.

Note: the screws do not align the same way in both ends, so be sure the two levels, base, and shell, are all aligned correctly when you reassemble.



Service & Warranty Information

How to Get Service Under the Terms of the Limited One-Year Warranty

For warranty repair, follow the instructions below to obtain warranty service.

First, e-mail, write, call or fax an Authorized M.T.H. Service Center in your area or M.T.H. Electric Trains to obtain Repair Authorization. You can find the list of Authorized Service Centers on the M.T.H. website, www.mth-railking.com. Otherwise, contact M.T.H. (at e-mail: service@mth-railking.com; 7020 Columbia Gateway Drive, Columbia, MD 21046; tel: 410-381-2580; fax: 410-423-0009), stating when the item was purchased and describing the problem. If you contact M.T.H., you will be given a return authorization number to assure that your merchandise will be properly handled upon its receipt.

CAUTION: Make sure the product is packed in its original factory packaging including its foam and plastic wrapping material so as to prevent damage to the merchandise. The shipment must be prepaid and we recommend that it be insured. A cover letter including your name, address, daytime phone number, e-mail address (if available), Return Authorization number, a copy of your sales receipt and a full description of the problem must be included to facilitate the repairs. Please include the description regardless of whether you discussed the problem with a service technician when contacting the Service Center or M.T.H. for your Return Authorization.

Limited One-Year Warranty

All M.T.H. products purchased from an Authorized M.T.H. Train Merchant are covered by this warranty. See our website at www.mth-railking.com or call 1-888-640-3700 to identify an Authorized M.T.H. Train Merchant near you.

M.T.H. products are warrantied for one year from the date of purchase against defects in material or workmanship, excluding light bulbs, pick-up rollers and traction tires. We will repair or replace (at our option) the defective part without charge for the parts or labor, if the item is returned to an Authorized M.T.H. Service Center or M.T.H. Electric Trains within one year of the original date of purchase. This warranty does not cover damages caused by improper care, handling, or use. Transportation costs incurred by the customer are not covered under this warranty.

Items sent for repair must be accompanied by a return authorization number, a description of the problem, and a copy of the original sales receipt from an Authorized M.T.H. Train Merchant, which gives the date of purchase. If you are sending the item to M.T.H., call 410-381-2580, fax 410-423-0009, or e-mail the Service Department at service@mth-railking.com to obtain a return authorization number. If you are sending this product to an Authorized Service Center, contact that Center for their return authorization

This warranty gives you specific legal rights, and you may have other rights that vary from state to state

Service Department
M.T.H. Electric Trains
7020cmiona Biad Lay Ori Peassenger Cars
Columbia, Maryland 21046-1532



PARTICIPATING RETAILER LIST OCTOBER 2001

ALABAMA

SOUTHERLAND STATION HUNTSVILLE 256-533-4720

256-533-4720 railway@bellsouth.net

ARIZONA ARIZONA TRAIN

DEPOT MESA 480-833-9486 sales@arizonatraindep ot.com www.arizonatraindepot. com/

CALIFORNIA

DOLLHOUSES, TRAINS & MORE NOVATO 415-883-0388 kbecker@cmc.net

TIN PLATE JUNCTION OAKLAND 510-444-4780 TOYTRAINS@email.m

sn.com

COLORADO

MIZELL TRAINS Inc WESTMINSTER 303-429-4811 mizelltrains@cs.com www.mizelltrains.com

CONNECTICUT SHELTON RAILROAD

SYSTEMS SHELTON 203-924-8761 adriani@clearlight.com NEW ENGLAND HOBBY SUPPLY MANCHESTER 860-646-0610 hobbell@nehobby.com

DELAWARE

K R R B MODEL TRAINS INC. NEWARK 302-292-2779 info@krrb.com www.krrb.com

FLORIDA

LAKE WORTH 561-585-1982 jimmyt1982@aol.com www.depothobbies.co m

DEPOT HOBBY SHOP

COLONIAL PHOTO & HOBBY ORI ANDO

407-841-1485 trains@colonialphotoa ndhobby.com

WARRICK CUSTOM HOBBIES PLANTATION

954-370-0708 info@warrickcustomho bbies.com www.warrickcustomho bbies.com FRANK'S TRAINS & HOBBIES INC. OLDSMAR 813-855-1041

FTH@allhobbies.com www.allhobbies.com

READY TO ROLL

305-688-8868 rtrtrains@aol.com www.readytorolltrains.c

ILLINOIS

BIKE & CHOO CHOO CONNECTION SCHAUMBURG 847-882-7728 trainconnection@aol.c

INDIANA

Y. O. R. K. TRAINS MUNSTER 219-838-9999 yorktrains@aol.com

SAMUELSON'S TRAIN SHOP VALPARAISO 219-462-2708

LOUISIANA AMERICA'S TRAIN

YARD BATON ROUGE 225-926-5592

MAINE

WHEELS, WINGS & THINGS LUDLOW 207-532-6277 irc44@javanet.com

MARYLAND

ENGINE HOUSE HOBBIES GAITHERSBURG 301-590-0816 luciecerise@aol.com

J & B TRAINS HAGERSTOWN 240-420-4930

HOBBYTOWNUSA FREDERICK 301-694-7395

PURKEY'S TOY TRAINS SYKESVILLE 410-549-6061 wiley@oldmainline.co m

THE TRAIN ROOM HAGERSTOWN 301-745-6681

MASSACHUSETTS NORTHEAST TRAINS

PEABODY 978-532-1615 www.netrainscom MICHIGAN BRASSEUR ELECTRIC TRAINS INC. SAGINAW 517-793-4753 bob@traindoctor.com www.traindoctor.com

MISSOURI

SWITCH STAND SAINT LOUIS 314-781-4458 r41877@earthlink.com

MARK TWAIN HOBBY CENTER ST. CHARLES 636-946-2816 webmaster@hobby1.c

www.hobby1.com

NEW HAMPSHIRE TREASURED TOYS SALEM

603-898-7224 ttoys@treasuredtoys.com www.treasuredtoys.com

RAILROAD SPECIALTIES HUDSON 603-882-5566 crew@electrictrains.com www.electrictrains.com

NEW JERSEY TRAINS & THINGS TRENTON 609-883-8790

trainsanthings@aol.co

GRAND CENTRAL STATION KEARNY 201-955-6200 228gene@gateway.co

HOBSYMASTERS, INC RED BANK 732-842-6020

masters.com

hobbymasters@hobby

HOLLY BEACH TRAIN DEPOT WILDWOOD 609-522-2379 larry@pro-usa.net COAST TRAINS AND COLLECTIBLES WALL 732-556-9005 coasttrain@aol.com www.coasttrains.com

J & B TRAINS, INC. MAPLE SHADE 856-414-0092

BASE1130@aol.com

HOBBY SHOP MATAWAN 732-583-0505 hobbyshopnj.com

ATLANTIC RAILS HAMMONTON 609-567-8490 bobcap@pics.com www.atlanticrails.com

RIDGEFIELD HOBBY RIDGEFIELD 201-943-2636

COLUMBUS TRAIN STATION COLUMBUS 609-518-1800

NEW YORK

AURORA RAILS & HOBBIES EAST AURORA 716-652-5718 rk82141@aol.com

AMERICANA STORE TIVOLI 845-757-4246 mthdepot@valstar.net

NASSAU HOBBY CENTER, INC. FREEPORT 516-378-9594 Charlienassau@aol.co

KROSS HARDWARE WEST BABYLON 631-669-3069 t989@aol.com

CITY DEPOT, INC.
NEW HAMPTON
845-374-3010
citydepot@frontiernet.n
et

NORTH CAROLINA DRY BRIDGE STATION MOUNT AIRY 336-786-9811

mikek@drybridgestatio n.com www.drybridgestation.c

THE FREIGHT YARD SMITHFIELD 919-934-6229 disbissette@aol.com

TRAINS LTD. CHARLOTTE 704-56 6-9070 modelrrs@bellsouth.ne t www.trainsltd.com

THE ROUNDHOUSE & BACKSHOP CARY 919-465-0810

OHIO
DIXIE UNION
STATION
MASON
513-459-0460
rockylane@core.net
www.dixieunionstation.

RICK'S TOY TRAINS TOLEDO 419-478-0171

T & K HOBBY SHOP BRIDGEPORT 740-633-6607 salea@tkhobbies.com www.tkhobbies.com

TRAINS-N-THINGS CANTON 330-499-1666 trains@sssnet.com

PARMA HOBBY CLEVELAND 216-741-6440 info@parmahobby.com

GLEN'S TRAIN SHOP AKRON 330-253-6527

E & S TRAINS AKRON 330-745-0785

GRAND PACIFIC JUNCTION OLMSTEAD FALLS 440-235-4777 gpimrr@juno.c om HUDSON TOY, TRAIN & HOBBY HUDSON 330-653-2997 ejpickens@aol.com

DAVIS ELECTRONICS MILFORD 513-831-6425 davistrains@fuse.net www.davistrains.com

SANDY'S HOBBY'S & COLLECTIBLES ELYRIA 440-365-9999 sandyshobb@aol.com

ERIE RAILWAY DEPOT TROY 937-440-9972 orvile@gte.net

CLEARVIEW TRAIN & HOBBY LORAIN 440-277-4488 klogar@erienet.net www.clearviewtrainand hobby.com

PENNSYLVANIA FAIRCHANCE PHARMACY FAIRCHANCE 724-564-7817 mthdealer@aol.com www.hhs.net/fairchance

THE STATION NEW CUMBERLAND 717-774-7096 station@paonline.com

BUSSINGER TRAINS AMBLER 2 15-628-2366 choochoos@icdc.com www.icdc.com/~btrains

CHARLEROI SWEEPER CENTER CHARLEROI 724-483-3397

AMERICAN HOBBY CENTER ALIQUIPPA 724-378-3930 american@icubed.com

CRANBERRY HOBBY DEPOT CRANBERRY TWP 724-776-3640 JAdams6113@aol.com

12 www.citydepot.com Premier Bi-Level Passenger Cars

ALLENTOWN TOY TRAIN SERVICE ALLENTOWN 610-821-0740

ON THE RIGHT TRACK ALTOONA 814-942-4345

JIM'S TRAIN SHOP HOMER CITY 724-479-2026 sudsy@stargate.net

YE OLDE TRAIN & CHRISTMAS SHOPPE BOYERTOWN 610-369-0755 www.yeoldetrain.com

TOBY TYLER'S HOBBY CENTER PITTSBURGH 412-653-5030 tobytyler111@cs.com

BUSTLETON TRAIN SHOP PHILADELPHIA 215-698-7266

CHESTNUT TOYBOX PHILADELPHIA 215-545-0455 chestnuttoy@earthlink.net

THE CABOOSE LEHIGHTON 570-386-5352 www.thecaboosehobbi es.com victen@ptd.net

SOUTH CAROLINA EMERALD TRAIN & HOBBY

GREENWOOD 864-223-2247 **TENNESSEE**

MODEL RAILROAD & HOBBY SHOP MEMPHIS 901-384-6500 mrhs99@earthlink.net www.modelrailroadand

TEXAS HOBBY TIME AMARILLO 806.352.9660 don.l.harris.@hobby-

hobby.com

time.com

VIRGINIA TRAIN DEPOT MANASSAS 703-335-2216

NORGE STATION WILLIAMSBURG 757-564-7623 norgetrains@cs.com

NUTBUSH EXPRESS VICTORIA 804-696-1902 thenutbushexp@meck com.net

TOY TRAIN CENTER RICHMOND 804-288-4475

T S G HOBBIES WARRENTON 540-347-9212 tripi@mnsinc.com www.mnsinc.com/tripi/t

CHESTERFIELD HOBBIES MIDLOTHIAN 804-379-9091 chsthobb@erols.com www.chesterfieldhobbi es.com

DAVIS HOBBY SUPPLIES PORTSMOUTH 757-397-1983 ralph@davishobby.com www.davishobby.com

LOCUST GROVE TRAINS LOCUST GROVE 540-854-8955 Igtrains@aol.com www.locustgrovetrains. com

WEST VIRGINIA PATRICK'S TRAINS WHEELING 304-232-0714 trains@patstrains.com www.patstrains.com

WISCONSIN SOMMERFELD'S TRAINS BUTLER 262-783-7797 questions@sommerfel ds.com G B T V & TRAINS GREEN BAY 920-496-9697 rrtycoon@netnet.net

GRAMPA'S TRAIN SHOP RICE LAKE 715-234-2996 grampastrainshop@ya hoo.com

THE TRAIN STORE WAUKESHA 262-650-6675

HOBBY OUTLET FOND DU LAC 920-924-3770 hobby_outlet@hotmail.

CANADA ONTARIO

CREDIT VALLEY
RAILWAY COMPANY
STREETSVILLE
905-826-1306
CVRCO@globalserve.
net

TOY TRAIN WORKSHOP CUMBERLAND 613-833-3125 info@toytrainworkshop

www.toytrainworkshop.

THE TRAIN ROOM FERGUS 519-787-3280